



Date: 11 March 2003

---

## **Floppy drive cable problems**

A number of users have reported problems with floppy disk drives not operating after transport. Internal inspection reveals the power and/or data cables have fallen out.

The solution is to glue the power and data cables to the floppy disk drive using neutral cure silicone sealant. Note: silicone sealant that is not "neutral cure" releases a mild acid when it cures. This acid attacks the PCB copper, possibly causing a premature failure.

Place a daub of silicone sealant on the locking tab of the power connector and on the locating tab of the data connector after the cable has been inserted. Leave the sealant to dry for 24 hours before movement