

Event Event Plus

Control Consoles

TBJLT096.doc



Date: 01 October 2004

New Software Release V3.2.2

Jands has released Event software version 3.2.2 for 24, 36, 48, and 60 channel consoles. This software version supersedes all previous releases and may be retrofitted into all Event consoles that are fitted with V3 software. This software includes the following change:

Stack control

Previously, if a chase had been set to crossfade between steps, then when this chase was used in a stack this facility was disabled in favour of the Infade and Outfade associated with the stack.

This has been changed in V3.2.2 as follows:

When a chase is loaded in a stack, and that chase is set to crossfade between steps, then:

- During the Stack Infade and Outfade periods the crossfading between steps is disabled as before,
- When the stack is not Infading or Outfading, the crossfading between steps now operates.

When a chase is not in a stack it behaves normally.